





Phone 408.221.8247

****Assembly Notes - If not using dust boots, skip to step 3****

- 1a. Front – we recommend trimming the upper 'lip' of the dust boot.
- 1b. Press the boot firmly down to the base of the shock and gather together 5 rings. Apply Zip tie.





- 2a. Rear – we recommend trimming the first full ring at the top.
- 2b. Firmly seat the dust boot and gather together 4 rings. Apply zip-tie.



- 3a. KYB, Bilstein, Tokico, Koni Street/Race – Place bump stop on shaft, spacers if provided, then provided washer.
- 3b. For Koni Sport shocks – Place Koni 3mm slotted spacer on shaft* followed by (3) 3mm FCM spacers (past kits used a single 9mm spacer), then the bump stop (oriented as below) and M12 washer.

***NOTE:** On the front Koni Sport, you may omit the slotted Koni 3mm thick spacer. It is **required** on the rear.





4. If using risers with FCM shock mounts, put them on the shock mount now and refer to the FCM shock mount procedure. If using the older style spring spacer shown below, put it on the lower spring perch as shown.



Risers, used only with FCM shock mounts



Older-style spring spacer (no longer sold)

5. Add spring, shock mount, lock washer and shock nut. Tighten to 30 lb-ft. If using FCM shock mounts, refer to those installation instructions at this point.



6. Mount shock per factory manual. Be sure to have car aligned as soon as possible if the ride height was changed.